



Product Information

- PVC cards
- Red, Green, Yellow
- 30 mil









IDEAL TO HIGHLIGHT YOUR OFFERS & PROMOTIONS

Evolis PVC cards are the ideal support for outstanding printouts. Their even and flat surface ensures flawless moves under the print head (minimizing the risk of damage) and printouts with vivid colors and well-defined barcodes.

Color PVC cards are the perfect choice for price tag labelling when you need to highlight specific messages. Use them with Evolis monochrome ribbons to bring a twist to your shelves!

ADVANTAGES

Color cards are an easy and aesthetic way to manage your communication and to add color to monochrome prints, making your tags more distinctive and noticeable. They are ideal to highlight your offers and promotions: Today's Special, Offer of the week, Organic produce, Locally sourced, Gluten free, Recommended, etc.

Made from PVC, they are flexible but very resistant and solid.

Tested and validated by Evolis R&D and Quality departments, these consumables bring you printing quality and reliability.

GENERAL SPECIFICATIONS

Features:

- Cards in PVC Blank solid color PVC Mirror finish
- Compliant with ISO CR-80 (ISO 7810) standards
- Dimension: 85.6 mm x 54 mm (3 3/8" x 2 1/8")
- Thickness: 0.76 mm / 30 mil

Compatibility and packaging:

PART#	COLOR	PANTONE CODE	PACKAGE	EDIKIO ACCESS	EDIKIO FLEX	EDIKIO DUPLEX
C4301	RED	PMS 200	1 box of 100 cards	•	•	•
C4401	GREEN	PMS 3415	1 box of 100 cards	•	•	•
C4101	YELLOW	PMS 102	1 box of 100 cards	•	•	•

Storage Information:

The cards shall be capable of functioning for up to 2 years after purchase if stored in a cool, dry environment and having remained unopened from the original packaging. Temperature of storage must be between 15-30°C (59-86°F) and at RH between 10-60%. Once opened, avoid dust, direct sunlight, high humidity and high temperatures. Do not place near solvent or other chemicals.

INSTRUCTIONS FOR USE

In order to optimize the printing quality and card durability:

- Do not use cards that have been damaged, folded or dropped on the floor.
- Do not touch the printable surface of the cards in order to preserve print quality.
- Do not use in high temperature conditions. Do not place near heat sources or open flames (degradation above 60°C/140°F). Avoid thermal shock.
- Avoid dishwasher and chemicals, wash your printed cards using clean cold water.